



Key Fob Programming Instructions

Key fob Programming – the control box comes preprogrammed to the two supplied remote key fobs. If for any reason you should program them or additional key fobs follow the following procedure:

Confirm that the box is turned on (the status LED should be lit green).

Press and hold the round work light button for 6 seconds. The LED will flash red 3 times to indicate program mode.

Press and hold button I (see figure 9 below) on the first key fob for 2 seconds then release. Press button I for 2 seconds on the second key fob.

Repeat for each additional key fob that is to be programmed.

Let box stand until Status LED returns to green. Programming is complete.

The control box will learn a maximum of 4 key fobs. All key fobs must be programmed at the same time. Programming an additional key fob at a later date will erase all previously stored key fobs.

Figure 1 – Programming Box to Key Fob

